


DWZ100A



For 208-240V, connect one of the line wires to terminal N.
Do *NOT* bring any neutral wire to this terminal.